

GRAB-IT™ CUTOUT FUSE TUBE REMOVAL TOOL

OPERATION MANUAL

STEP 1



Sweep the Grab-It™ behind the barrel of the fuse. Position the Grab-It™ so that the fuse rests in the notch, located between the probe and integrated forks.

STEP 2



Slide the Grab-It™ upward so that the integrated forks engage the fuse's cradle.

STEP 3



Lift and lower fuse assembly from the cutout body. Reverse the steps for fuse tube installation.

FUNCTIONS:

- Offers a safe, simple method to remove and install overhead fuse barrels
- Provides improved control of fuse barrels (even in high winds)
- Reduces accidental drops

MODELS:

GRAB-IT-1	GRAB-IT-2	GRAB-IT-3	GRAB-IT-4	GRAB-IT-5
100 AMP Cutout Fuse Tube Removal Tool	100 & 200 AMP Cutout Fuse Tube Removal Tool	SMU-20 Power Cutout Fuse Tube Removal Tool	100 AMP Double Bar Cradle Fuse Tube Removal Tool	Current Limiting (CL) Cutout Fuse Tube Removal Tool

