

## **REX CLAMP™**

### USER MANUAL



The Rex Clamp™ is an easy-to-use clamp designed to control tails when using a Come Along or strap hoist type pulling device.


#### **Features:**

- Variable width jaw notches accommodate conductor sizes up to 1.15" OD.
- Clamp can be set tight to the conductor or allowed to slide if needed.
- Integrated slot can accommodate single straps up to 3" wide.

**To avoid breaking, do not attempt to load more than 1 strap in the slot.**


- Rotating arm engages to provide positive lock to strap and conductor.

#### **STEP 1**




Slide clamp over strap.  
Place the tail in the jaws.

#### **STEP 2**



Lock the rotating arm in  
place.

#### **STEP 3**



If desired, set the clamp  
tight to the conductor,  
or allow it to slide by using a  
larger slot.



(828) 323-8914



(828) 323-8410



sales@utilityolutionsinc.com



utilityolutionsinc.com

101 33<sup>RD</sup> STREET DRIVE SE • HICKORY, NC 28602